Test Sockets Using Secure Mode

When using secure mode in the DeviceMaster, it is necessary to use a Secure Sockets Layer (SSL) application. Telnet and Secure Shell (SSH) will not transfer data across the socket connections to/from serial ports.

As a result of this, a SSL application will be required. This document will discuss the usage of an open source SSL application.

Download openssl for windows at <u>http://www.slproweb.com/products/Win32OpenSSL.html</u> selecting the appropriate version for your environment. For 32 bit windows select Win32 OpenSSL v0.9.81. For 64 bit windows select Win64 OpenSSL v0.9.81.

After downloading, execute the file. For this document it will be assumed that the default installation will be used and we will show the paths and instructions based on the default installation.







Click OK



Click <u>N</u>ext



 \underline{A} ccept the agreement and click \underline{N} ext

1🕏 Setup - OpenSSL (32-bit)
Select Destination Location Where should OpenSSL (32-bit) be installed?
Setup will install OpenSSL (32-bit) into the following folder.
To continue, click Next. If you would like to select a different folder, click Browse.
C:\OpenSSL Browse
At least 29.8 MB of free disk space is required.
< <u>Back</u> <u>Next</u> Cancel

Click Next

i [#] Setup - OpenSSL (32-bit)
Select Start Menu Folder Where should Setup place the program's shortcuts?
Setup will create the program's shortcuts in the following Start Menu folder.
OpenSSL Browse
< Back Next > Cancel





Click <u>N</u>ext



Click Install





If desired, unselect and select your choice Click <u>F</u>inish

Create a shortcut on the desktop.

On the desktop right-click and select New>Shortcut from the pop-up menu

Click on Browse



Path to the c:\OpenSSL\bin\openssl.exe file



Click <u>N</u>ext



Enter a name to be displayed. Click Finish

Configure the DeviceMaster for basic security. This document will NOT discuss The configuration or addition of Key and Certificate Management. For this example we will be using the default key in the DeviceMaster.



Open PortVision Plus and Scan the network to discover the DeviceMaster.

Highlight the DeviceMaster and select Web Mgr



The web page will open to the Server Configuration page

Comtrol Corporation - DeviceMa	aster RTS N	S-Link 7.14	- Windows	ln 💶 🗖	X		
COC V ktp://192.168.2.42/h	nome.asp 🔽	8 4 >	K 🛃 Goog	e 🖌	•		
<u>Eile Edit View Favorites Tools</u>	<u>H</u> elp						
🚖 Favorites 🛛 👍 🚼 Google 🥫	FTP 🥫 Com	trol 🙋 8510	📶 Wireshar	k 🙋 Air 🙋	11		
Comtrol Corporation - Dev	🗿 • 🖻	- 🖃 🖶	▼ Page ▼	<u>S</u> afety •	»		
	Serv	er Cor	nfigura	ation @	^		
	Softwa	are:	NS-Link 7	.14			
	IP Con	fig:	Static				
• ((4))).	IP Add	ress:	192.168.2	2.42			
	IP Net	mask:	255.255.0	0.0			
	IP Gat	eway:	192.168.2				
DEV/CE-MASTER	Configure Network						
/	Configure Security						
	Config	ure Email	Message	5			
	Config	ure RFC10	006 (ISO d	over TCP)			
					-		
	Port 1	Port 2	Port 3	Port 4			
TCP Connection Status							
Enabled:	No	No	No	No			
Local:	0.0.0.0:0	0.0.0:0	0.0.0:0	0.0.0:0			
Remote:	0.0.0.0:0	0.0.0.0:0	0.0.0.0:0	0.0.0.0:0			
Rx bytes:	0	0	0	0			
Tx bytes:	0	0	0	0			
Serial Status					~		
Done	Internet	et	- 66 -	100%	•		

Click on Port 1

Comtrol Corporation - DeviceMa	aster RTS N	S-Link 7.14	- Windows	ln 💶 🗖	\times			
COC V # http://192.168.2.42/home.asp V 🖄 👉 🗙 Google 👂								
Elle Edit View Favorites Tools Help								
🖕 Favorites 🛛 👍 🔧 Google 🙋 FTP 🙋 Comtrol 🙋 8510 📶 Wireshark 🍭 Air 🙋 11								
🌈 Comtrol Corporation - Dev 🍡 🏠 🔹 🗟 🔹 🖾 🖷 🖶 Page 🔹 Safety 🔹 🎇								
Server Configuration @								
Software: NS-Link 7.14								
	IP Cor	nfig:	Static					
• • • • • • •	IP Add	lress:	192.168.2	2.42				
	IP Netmask:		255.255.0.0					
	IP Gateway:		192.168.2.254					
DEV/CE+MASTER	Configure Network							
/	Config	jure Secur	ity					
	Config	jure Email	Message	5				
	Configure RFC1006 (ISO over TCP)							
	Port 1	Port 2	Port 3	Port 4				
TCP Connection Status								
Enabled:	No	No	No	No				
Local:	0.0.0.0:0	0.0.0.0:0	0.0.0.0:0	0.0.0.0:0				
Remote:	0.0.0.0:0	0.0.0.0:0	0.0.0.0:0	0.0.0.0:0				
KX bytes:	0	0	0	0				
Sorial Status	U	U	U	U				
Senar Status	-			-	~			
http://192.168.2	😌 Intern	et	- 🐴 -	🔍 100% 🔻	:			

Set the serial port to the parameters you wish to use and then scroll down to the TCP Connection Configuration

	<u> </u>
Comtrol Corporation - DeviceMaster RTS NS-Link	7.14 - Windows In 💶 🗖 🔀
🚱 🗢 🖉 http://192.168.2.42/editPort.asp 💌 🗟	🔄 🗙 🛃 Google 🖉 🖓
<u>File E</u> dit <u>V</u> iew F <u>a</u> vorites <u>T</u> ools <u>H</u> elp	
🚖 Favorites 🛛 🚔 Google 🙋 FTP 🙋 Comtrol 💋	8510 📶 Wireshark 🙋 Air 🙋 11
Comtrol Corporation - Dev	📄 🝷 Page 👻 Safety 👻 🂙
Stop Bits:	1 🗸 🔺
Flow:	none 💌
DTR:	off 😪
RTS:	off 😪
EOL:	disabled 🔽 00 00
Input Timeout:	0 ms
Rx FIFO Disable:	
Tx Complete After Close:	
TCP Connection Configuration 🖗	
Enable:	
Listen:	
Connect To:	0.0.0.0 To F
Connect On:	🗌 Always 🔲 Data
Disconnect On:	Idle INo DSR
Idle Timer:	300
Telnet Com Port Control Option (RFC 2217	7):
	~
😜 Internet	🖓 🔹 🔍 100% 👻 🛒

Place a checkmark in the Enable box.

Comtrol Corporation	n - DeviceMaster RTS NS-Link 7.14 - \	Windows In 🔳 🗖 🔀
🔆 🔁 🗢 🖉 http://1	192. 168. 2. 42/editPort.asp 👻 🖄 😽 🗙	Google
Eile Edit View Favo	orites <u>T</u> ools <u>H</u> elp	
🖕 Favorites 🛛 👍 💈	🖥 Google 🥫 FTP 🙋 Comtrol 🙋 8510 🔽	🛿 Wireshark 🙋 Air 🙋 11
Comtrol Corporation - D	ev 🚺 🕯 🔹 🖨 🗸	Page • Safety • *
🗌 Enable Serial To	Ethernet	
🔲 Enable Ethernet	To Serial	
Enable Ethernet	Receive From Any IP Address	
Target IP Address	Target Port (serial->eth)	Source Port (seri
0	0	0
0	0	0
0	0	0
0	0	0
0	0	0
0	0	0
0	0	0
0		0
		0
UDP Listen Port:	7000	≡.
Clone Port	Undo Changes Save Help	
<		
/goform/setPortC	😝 Internet	🖓 🔹 💐 100% 👻 🛒

Scroll to the bottom of the page and click on Save/



Now you should see "Yes" in the enabled row for Port 1.

Comtrol Corporation - DeviceMa	ster RTS N	S-Link 7.14	- Windows	In 💶 🗖	×			
💽 🗢 🙋 http://192.168.2.42/h	😋 🗢 🖉 http://192.168.2.42/home.asp 💌 🖄 🐓 🗙 🌄 Google 🛛 🔎 🗢							
Eile Edit View Favorites Tools	<u>H</u> elp							
🖕 Favorites 🛛 👍 😽 Google 🍘	FTP 🥫 Com	trol 🙋 8510	🗖 Wireshar	k 🙋 Air 🙋 1	11			
Comtrol Corporation - Dev	<u>6</u> • 5) - 🖃 🖶		<u>S</u> afety ▼	»			
🔥 👔 Server Configuration 🥑								
	Softwa	are:	NS-Link 7	/.14				
	IP Con	fig:	Static					
\cdot	IP Add	ress:	192.168.2	2.42				
	IP Net	mask:	255.255.0	0.0				
	IP Gate	eway:	192.168.2	=				
DEV/CE+MASTER	Config	ure Netwo	ork		-			
/	Config	ure Secur	ity					
	Config	ure Email	Message	5				
	Config	ure RFC10	006 (ISO d	over TCP)				
	Port 1	Port 2	Port 3	Port 4				
TCP Connection Status								
Enabled:	Yes	No	No	No				
Local:	0.0.0:0	0.0.0:0	0.0.0:0	0.0.0:0				
Remote:	0.0.0:0	0.0.0:0	0.0.0:0	0.0.0.0:0				
Rx bytes:	0	0	0	0				
Tx bytes:	0	0	0	0				
Serial Status					~			
Modo.	Interne	et	<u>versss</u>	€ 100% -				

Click on the Configure Security link

U		5			_
Comtrol Corporation - DeviceMa	ister RTS N	S-Link 7.14	- Windows	In 💶 🗖	×
💽 🗢 🙋 http://192.168.2.42/h	ome.asp 🔽	8 4 >	K 🛃 Goog	le 👂	-
Eile Edit View Favorites Tools	<u>H</u> elp				
🚖 Favorites 🛛 👍 🚼 Google 💋	FTP 🥫 Com	trol 🙋 8510	🗖 Wireshar	k 🟉 Air 🏉	11
Comtrol Corporation - Dev	🙆 • 🖻	- 🖃 🖶	▼ Page ▼	<u>S</u> afety •	»
	Com			-	^
	Serv	er cor	ingura		•
	Softwa	ire:	NS-Link 7	.14	
	IP Con	fia:	Static		
	IP Add	ress:	192.168.2	2.42	
	IP Net	mask:	255.255.0.0		
	IP Gat	IP Gateway:		2.254	
DEVCEMASTER	Configure Network				
	Config	ure Secur	ity		
	Configure Email Messages				
	Config	ure RFC1()06 (ISO d	over TCP)	
	Dort 1	Port 2	Dort 2	Port 4	
TCP Connection Status	FUILT	FUIL 2	FULS	FULT	
Enabled:	Yes	No	No	No	
Local:	0.0.0.0:0	0.0.0.0:0	0.0.0.0:0	0.0.0.0:0	
Remote:	0.0.0.0:0	0.0.0.0:0	0.0.0.0:0	0.0.0.0:0	
Rx bytes:	0	0	0	0	
Tx bytes:	0	0	0	0	
Serial Status					2.0
Modor	DC_777	DC-777	DC-777	DC-777	
http://192.168.2	😸 Interne	et	- 🖓 -	💐 100% 🔻	

Here you will set the DeviceMaster to use secure modes.



Checkmark "Enable Secure Data Mode" Checkmark "Enable Secure Config Mode" Remove the checkmark on "Enable SNMP"



Click Save



Click OK (which will return you to the previous screen). Close the web browser.

Back to PortVision Plus.

Highlight the DeviceMaster and select the Reboot icon on the launch bar.





Click Yes to reboot

🕅 PortV	ision Plu	S										
<u>F</u> ile F <u>o</u> lde	er <u>D</u> evice	<u>V</u> iew <u>T</u>	ools <u>H</u> elp									
Scan	Refresh	Config	Save	🍌 Load	Dipload	C Reboot	QQ Web Mgr	Notes	🍤 Help	6 About	Exit	
POF	RTVISIO	ON° LIS	Use menu area.	ı or toolbar	to add de	vice-speci	iic notes in	this 💉	D	2	000#	
Sca	an Results [1 of 1 onlin	e] Der	vice Name		Model	A	IP Addr	MAC Add	ress	Software Version	n Status
				Device	09:00:60	_RTS-₩ (I	(192.	100.2.42	00:C0:4E	09:00:60	NS-LINK 7, 14	Rebooung
For Help, p	ress F1									Sc	an Results 1	1 Ready //

PortVision Plus will show the DeviceMaster as rebooting in the status column.

Once back on line you will now notice a "lock" next to the Device Name Indicating that it is now in secure mode of operation.



Highlight the DeviceMaster and select Web Mgr



When the browser opens you will receive a notice that there is a problem With the websites security. This is due to using the default certificate key.



Click on "Continue to website (not recommended)"



When the web page opens the URL will be in red due to the Certificate error.

Execute the new OpenSSL shortcut

openssl.exe	- 🗆	×
OpenSSL>		
		•

enter "s_client -connect IP_Address:Socket" without quotes and where IP_Address is replaced by the IP Address of the DeviceMaster (in this example 192.168.2.42) and Socket is replaced by the socket number assigned (in this example 8000) to the serial port, then press Enter, J Note the colon between the IP_Address and Socket. This is required.





several lines will be displayed

ending with:



Press any keys and the keystroke should be echoed to the screen.



press enter and the entered keystrokes will be re-displayed.



In the web page you should see that Port 1 shows: Local: 0.0.0.0:8000 Remote: IP_Address:Socket of the connected PC

in this example 192.168.2.10:1329

Rx bytes: The number of bytes sent by the PC.

Comtrol Corporation - Device	Master	RTS NS-Link 7.	.14 - Wind	ows Intern	e 🗖 🗖	$\left \times\right $
🔆 🗢 💌 🙋 https://192.168.2.4	12 /hc 💙	😵 Certificat	2 f ×	Google	P	•
Eile Edit View Favorites Too	ls <u>H</u> elp	•				
🖕 Favorites 🛛 👍 🔧 Google 🌡	FTP	🥖 Comtrol 🥫 8	510 🗖 Wire	eshark 🥫 A	ir 🤌 11	»
Comtrol Corporation - Dev		- 🔊 - 🖃	🖶 🝷 Pag	e 🕶 <u>S</u> afety	Tools	»
		Server (Config	jurati	on ø	^
		Software:	NS-	Link 7.14		
		IP Config:	Sta	tic		
\cdot		IP Address:	192	.168.2.42		
		IP Netmask	: 255	.255.0.0		
		IP Gateway: 192.168.2.254				
DEV/CE-MASTE	R	Configure N	etwork			
		Configure S	ecurity			
		Configure E	mail Mes	sages		
		Configure R	FC1006 (ISO over	TCP)	
	Port 1	L	Port 2	Port 3	Port 4	
TCP Connection Status						
Enabled:	Yes		No	No	No	
Local:	0.0.0.	0:8000	0.0.0.0:0	0.0.0:0	0.0.0:0	
Remote:	192.1	68.2.10:1329	0.0.0.0:0	0.0.0:0	0.0.0:0	
Rx bytes:	11		0	0	0	
Tx bytes:	0		0	0	0	
Serial Status						~
		😜 Internet		- @ -	🔍 100% 🕙	•

This confirms connection and data transfer.

Back to OpenSSL Ctrl-C to disconnect



q (and Enter) to quit and close the window.